

# RDM40

## Four Channel Rotary DJ Mixer

The RDM40 is a fully analog four channel rotary DJ mixer. Channel 1-3 feature a phono / line input and Channel 4 features a Line / Microphone Input.

For your mixing pleasure we've developed two different three band isolator-banks and built them into the RDM40. One is set on the master and there's another one on each channel. While the master isolator is quite steep and raw, the character of the channel isolator is more soft and smooth. You can totally release your creativity with the combination of those two isolators and it's big fun to mess around with these knobs.



### INPUTS

- 4 Channels
  - 3x Line/Phono
  - 1x Line/Microphone

Each channel has the following parameters:

- Gain (+/-12dB)
- Level
- 3-Band Isolator (Full Kill, not Equalizer)
- Send (you can send the signal to an external effect processor such as a delay or reverb)
- Signal Level indication LED
- PFL Switch (to select which channel is on the headphones)
  
- 3-Band Master-Isolator
  
- Potentiometer to level the Return-signal

### OUTPUTS

- Master Out (XLR balanced)
- Booth Out (Jack balanced)
- Record Out (RCA balance)
- 1x Headphone with the following parameters:
  - Level phones
  - Cue Mix / PFL Mix
- Solid metal housing made in Switzerland
- 2x analog VU-meters which indicate the program master (PGM) or the CUE / PFL
- Built in linear Power Supply Unit (PSU) switchable from 115V to 230V

### DIMENSION

345 x 360 x 190 mm (13.6 x 14.2 x 7.5 inches)

### WEIGHT

5.5 kg (12.1 lbs)

### OFFICIAL RETAIL PRICE

3'490 CHF excl. VAT & delivery

Varia Instruments GmbH  
Holzikofenweg 1  
CH-3007 Bern  
Switzerland  
info@varia-instruments.com  
www.varia-instruments.com

**VARIA  
INSTRUMENTS**