

RDM20

Two Channel Rotary DJ Mixer

The RDM20 is a fully analog two channel rotary DJ mixer, with one phono and two line inputs on each channel. For your mixing pleasure we've developed two different three band isolator-banks and built them into the RDM20. One is set on the master and there's another one on each channel. While the master isolator is quite steep and raw, the character of the channel isolator is more soft and smooth. You can totally release your creativity with the combination of those two isolators and it's big fun to mess around with these knobs - believe us!

The RDM20 has two balanced outputs (House XLR, Booth Jack), as well as a separate steady recording output (cinch). The linear power supply unit is built in, no extra mains adapter needed. Analog VU-meters are indicating the level of the master.



INPUTS

Phono: RCA 47k Ω | RIAA response +1/-0.5dB
Line: RCA 68k Ω | 20Hz-20kHz +/-0.5dB)

CHANNEL ISOLATOR

Slope 12db/oct
20-125Hz | 125-4'000Hz | 4'000-20'000Hz
Cut -inf dB, Boost +9dB

MASTER ISOLATOR

Slope 24db/oct
20-280Hz | 280-4'200Hz | 4'200-20'000Hz
Cut -inf dB, Boost +9dB

OUTPUTS

House: XLR Balanced 100 Ω | +4dBu nominal
Booth: Jack Balanced 100 Ω | +4dBu nominal
Rec Out: RCA Unbalanced 100 Ω | -10dBV nominal
Phones: 1W into 70 Ω

DIMENSIONS

300 x 235 x 152 mm (11.81 x 9.25 x 5.98 inches)

WEIGHT

3.5 kg (7.7 lbs) with built in power supply

OFFICIAL RETAIL PRICE

2'190 CHF excl. VAT & delivery

Varia Instruments GmbH
Holzikofenweg 1
CH-3007 Bern
Switzerland
info@varia-instruments.com
www.varia-instruments.com

**VARIA
INSTRUMENTS**